

INDOOR AIR QUALITY CORPORATION
1675 N COMMERCE PKWY
WESTON, FL 33326

Certificate of Mold Analysis

Prepared for: INDOOR AIR QUALITY CORPORATION
Phone Number: (407) 463-8651
Fax Number: (954) 332-1005
Project Name: GENERAL CRANE USA
Test Location: 1360 N.W. 33RD ST.
POMPANO BEACH, FL 33069
Chain of Custody #: 453642
Received Date: December 15, 2010
Report Date: December 15, 2010



Erika Piechowski, Technical Manager



Carlos Ochoa, Quality Control Manager

Currently there are no Federal regulations for evaluating potential health effects of fungal contamination and remediation. This information is subject to change as more information regarding fungal contaminants becomes available. For more information visit <http://www.epa.gov/mold> or www.nyc.gov/html/doh/html/epi/mold.shtml. This document was designed to follow currently known industry guidelines for the interpretation of microbial sampling, analysis, and remediation. Since interpretation of mold analysis reports is a scientific work in progress, it may as such be changed at any time without notice. The client is solely responsible for the use or interpretation. PRO-LAB/SSPTM Inc. makes no express or implied warranties as to health of a property from only the samples sent to their laboratory for analysis. The Client is hereby notified that due to the subjective nature of fungal analysis and the mold growth process, laboratory samples can and do change over time relative to the originally sampled material. PRO-LAB/SSPTM Inc. reserves the right to properly dispose of all samples after the testing of such samples are sufficiently completed or after a 7 day period, whichever is greater.



LAB # 163230

For more information please contact PRO-LAB at (954) 384-4446 or email info@prolabinc.com

Prepared for : INDOOR AIR QUALITY CORPORATION

Test Address : GENERAL CRANE USA

 1360 N.W. 33RD ST.
 POMPANO BEACH, FL 33069

ANALYSIS METHOD	Direct Microscopic Exam	INTENTIONALLY BLANK	INTENTIONALLY BLANK	INTENTIONALLY BLANK
LOCATION	BLDG 1 AIR RETURNS			
COC / LINE #	453642-3			
SAMPLE TYPE & VOLUME	SWAB			
SERIAL NUMBER	None supplied			
COLLECTION DATE	Dec 15, 2010			
ANALYSIS DATE	Dec 15, 2010			

IDENTIFICATION	Mold Present	Raw Count	Spores per m ³	Percent of Total	Raw Count	Spores per m ³	Percent of Total	Raw Count	Spores per m ³	Percent of Total
Cladosporium	X									
Other Ascospores	X									
Other Basidiospores	X									

TOTAL SPORES	NA									
MINIMUM DETECTION LIMIT*	NA									

BACKGROUND DEBRIS	Not Applicable									
--------------------------	----------------	--	--	--	--	--	--	--	--	--

OBSERVATIONS & COMMENTS	No presence of current or former growth observed. Only normally settled spores observed.									
------------------------------------	--	--	--	--	--	--	--	--	--	--

Background debris qualitatively estimates the amount of particles that are not pollen or spores and directly affects the accuracy of the spore counts. The categories of Light, Moderate, Heavy and Too Heavy for Accurate Count, are used to indicate the amount of deposited debris. Increasing amounts of debris will obscure small spores and can prevent spores from impacting onto the slide. The actual number of spores present in the sample is likely higher than reported if the debris estimate is 'Heavy' or 'Too Heavy for Accurate Count'. All calculations are rounded to two significant figures and therefore, the total percentage of spore numbers may not equal 100%.

***Minimum Detection Limit.** Based on the volume of air sampled, this is the lowest number of spores that can be detected and is an estimate of the lowest concentration of spores that can be read in the sample. **NA** = Not Applicable.

Spores that were observed from the samples submitted are listed on this report. If a spore is not listed on this report it was not observed in the samples submitted.

Identification	Outdoor Habitat	Indoor Habitat	Possible Allergic Potential Not an opinion or interpretation	Comments
Cladosporium	The most common spore type reported in the air worldwide. Found on dead and dying plant litter, and soil.	Commonly found on wood and wallboard. Commonly grows on window sills, textiles and foods.	Type I (hay fever and asthma), Type III (hypersensitivity pneumonitis) allergies.	A very common and important allergen source both outdoors and indoors.
Ascospores	Common everywhere. Constitutes a large part of the airspora outside. Can reach very high numbers in the air outside during the spring and summer. Can increase in numbers during and after rainfalls.	Very few of this group grow inside. The notable exception is Chaetomium, Ascotricha and Peziza.	Little known for most of this group of fungi. Dependent on the type (see Chaetomium and Ascotricha).	
Basidiospores	Commonly found everywhere, especially in the late summer and fall. These spores are from Mushrooms.	Mushrooms are not normally found growing indoors, but can grow on wet lumber, especially in crawlspaces. Sometimes mushrooms can be seen growing in flower pots indoors.	Some allergenicity reported. Type I (hay fever, asthma) and Type III (hypersensitivity pneumonitis).	Among the group of Mushrooms (Basidiomycetes) are dry rot fungi Serpula and Poria that are particularly destructive to buildings.